





INSTALLATION EXAMPLES 907

Individual star-shaped SMATV installation



Individual installation for a single SAT receiver located on any of the outlets of the installation. An IF splitter is used to distribute the signal to all the outlets. The distributor has a DC path which permits the voltage feeding of the LNB. If more than one SAT receiver is installed the control signals of the LNB of the receivers will suffer interference.

Distribution with outlets in series



In distributions with outlets in series (outlets in cascade within the same house) several intermediate outlets are used, with input and output, and a terminal outlet.