

## ENTRANCE PANEL WITH KEYPAD

### Operation

When the lock release button of the telephone or monitor is pressed, the device - via the communication BUS (terminals D1, D2) - instructs the audio unit to open the door. The audio unit transmits this instruction to the numeric keypad (OUT connector). The numeric keypad then sends a direct voltage (terminals 11, 12) both to the electric lock, allowing the door to be opened, and to the ASC-050 accessory (terminals:  $\overline{L}$ , Ctrl2), closing the circuit of the stairs lighting.

### WIRED DIAGRAM

